# MODMASTER ADAPTABLE SPEEDLIGHT SOFTBOX

# SETUP - ASSEMBLY CAN BEGIN AT ANY POINT INSIDE THE SOFTBOX AND WITH ANY ARM



#### **OPEN SOFTBOX**

- **1.** Place softbox on large flat surface, mount side down, and release velcro strap.
- 2. Pull open edges of softbox, place both hands inside against left and right sides of material to spread softbox open.



### **SNAP ARMS INTO PLACE**

- **3.** Place one hand firmly over the base of an arm (assembly can begin with any arm) and push down until arm clicks into place.
- **4.** Proceed to the next arm, and work your way around until all 8 have been snapped in.



#### ATTACH DIFFUSERS

- **5.** The Savage Adjustable Softbox comes with both internal and external diffusers. Attach internal diffuser to the velcro tabs located about 4.5" from the top of the softbox.
- 6. Attach external diffuser to the velcro strip around the top outer edge of the softbox.

If mounting to a studio strobe with a Bowens mount, the softbox is now ready for use.

## SPEEDLIGHT USAGE - MOUNT UP TO 5 SPEEDLIGHTS AND AN UMBRELLA



#### ATTACH SPEEDLIGHT ADAPTER

- 1. Attach speedlight adapter to softbox mount, and turn the adapter clockwise until it snaps into place.
- 2. Use the side grip screws to tighten the orange padded disks to each side of your speedlight.



### ATTACH COMFORT GRIP HANDLE

- 1. Line up the track at the top of the comfort grip with the speedlight carriage on the opposite side of the mount from the release lever.
- Press the release lever up with the front edge of the comfort grip and then slide the comfort grip onto the track until the release lever pops down to lock into place. To release, pull up the release lever and slide handle off.



## **BREAKDOWN**



#### **DISSASEMBLE COMPONENTS**

- 1. Remove diffuser panels by pulling gently away from velcro strips.
- 2. Place the softbox on a large flat surface, front side facing down.
- Remove comfort grip handle by pressing release lever and sliding off.
  Remove the speedlight adapter from the softbox by pushing the small
- Remove the speedight adapter from the softbox by pushing the sm side lever, and turning the adapter counter clockwise to unlock.

#### COLLAPSE SOFTBOX

- 5. With one hand, gently lift up on the arm to relieve tension.
- **6.** With the other hand, press black release button to collapse arm.
- 6. Repeat step 5 & 6 until all 8 arms have been released.7. Place softbox and accessories into carry bag for safe storage.



Note: The release button will not release the softbox arms unless the arm has been pulled back to relieve the tension on the button.