

Camera Support - Nikon

Other Camera Brands

Model	Version Added	Required Run Modes	File Support	Tethered/Live View	Notes
Nikon Z7	12.0.0	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon Z6	12.0.0	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon Z50	12.1.5	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D6	20 (13.0.4)	Express for Nikon/for Nikon/Pro	NEF*	Yes/Yes	14-bit uncompressed and Lossless Compressed above ISO 409.600 (Hi 2) not supported
Nikon D5	9.1.1	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	12 bit uncompressed supported in 11.1.0 and later
Nikon D4s	7.2.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	RAW-S not supported
Nikon D4	6.4.5	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	RAW-S not supported
Nikon DF	7.2.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D3s	5.2.1	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D3X	4.8.3	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D3	3.7.9	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D2Xs	3.7.9	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D2X	3.7.9	Express for Nikon/for Nikon/Pro	NEF	Yes/No*	Tethered support for Windows only
Nikon D2Hs	3.7.9	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D2H	3.7.9	Express for Nikon/for Nikon/Pro	NEF	No/No	None

Model	Version Added	Required Run Modes	File Support	Tethered/Live View	Notes
Nikon D1X	3.7.9	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D1H	3.7.9	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D850	10.2.0	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	12 bit uncompressed supported in 11.1.0 and later
Nikon D810	7.2.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	RAW-S not supported
Nikon D810A	8.3.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	RAW-S not supported
Nikon D800	6.4.5	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	RAW-S not supported
Nikon D800E	6.4.5	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	RAW-S not supported
Nikon D780	20 (13.0.3)	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D750	8.3.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D700	4.8.3	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D610	7.2.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D600	7.2.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D500	9.2.0	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	12 bit uncompressed supported in 11.1.0 and later
Nikon D300s	5.2.1	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D300	3.7.9	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D200	3.7.9	Express for Nikon/for Nikon/Pro	NEF	Yes/No*	Tethered support for Windows only
Nikon D100	3.7.9	Express for Nikon/for Nikon/Pro	NEF	No/No	None

Model	Version Added	Required Run Modes	File Support	Tethered/Live View	Notes
Nikon D90	4.8.3	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D80	3.7.9	Express for Nikon/for Nikon/Pro	NEF	Yes/No	None
Nikon D70s	3.7.9	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D70	3.7.9	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D60	4.8.3	Express for Nikon/for Nikon/Pro	NEF	Yes/No	None
Nikon D50	3.7.9	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D40X	3.7.9	Express for Nikon/for Nikon/Pro	NEF	Yes/No	None
Nikon D40	3.7.9	Express for Nikon/for Nikon/Pro	NEF	Yes/No	None
Nikon D7500	10.2.0	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D7200	8.3.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D7100	7.2.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D7000	6.4.5	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D5600	10.1.0	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D5500	8.3.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D5300	7.2.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D5200	7.2.4	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D5100	6.4.5	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None

Model	Version Added	Required Run Modes	File Support	Tethered/Live View	Notes
Nikon D5000	5.2.1	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D3500	20 (13.0.3)	Express for Nikon/for Nikon/Pro	NEF	Yes/Yes	None
Nikon D3400	10.1.0	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D3300	8.3.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D3200	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D3100	6.4.5	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon D3000	5.2.1	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon P950	20 (13.1.0)	Express for Nikon/for Nikon/Pro	NRW	No/No	None
Nikon P330	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon P340	8.3.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon P7800	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon P7700	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon P7100	6.4.5	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon P7000	6.4.5	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon P6000	5.2.1	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon 1 AW1	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon J5	10.0.2	Express for Nikon/for Nikon/Pro	NEF	No/No	None

Model	Version Added	Required Run Modes	File Support	Tethered/Live View	Notes
Nikon J4	8.3.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon J3	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon J2	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon J1	6.4.5	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon V3	9.3.0	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon V2	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon V1	6.4.5	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon S1	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon Coolpix P1000	12.1.0	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon Coolpix A1000	12.0.3	Express for Nikon/for Nikon/Pro	NEF	No/No	None
Nikon Coolpix A	7.2.4	Express for Nikon/for Nikon/Pro	NEF	No/No	None