

Camera Compatibility

Canon

EOS 1100D / T3

EOS 1200D / T5

EOS 100D / SLi

EOS 500D / T1i / X3

EOS 550D / T2i

EOS 600D / T3i

EOS 650D / T4i

EOS 700D / T5i

EOS 750D / T6i

EOS 760D / T6s

EOS 50D

EOS 60D

EOS 70D

EOS 80D

EOS 5D Mark II

EOS 5D Mark III

EOS 5D Mark IV

EOS 5Ds / 5Ds R

EOS 6D

EOS 7D

EOS 7D Mark II

EOS 1D X

EOS 1D X Mark II

EOS 1D Mark IV

Nikon

D3100

D3200

D3300

D5000

D5100

D5200

D5300

D5500

D7000

D7100

D7200

D300 / D300s

D600

D610

D800 / D800e

D810 / D810a

D750

D700

D500

D90

D3 / D3s

D4 / D4s

D5

This camera does not support Live View