

Camera Compatibility List

Sony	A1, A9, A9II, A7M2, A7R2, A7S2, A7M3, A7M4, A7R3, A7R4, A7R5, A7S3, A7C, A6600, A6500, A6400, A6300, A6100, ZV-E10, ZV-E1, ZV-1, ILME-FX3
Nikon	D850, D780, Z fc, Z50, Z5, Z6, Z6 II, Z7, Z7 II, Z30, Z8
Canon	5DS, 5DS R, 5D MIII, 5D MIV, 6D MII, 6D, 80D, 90D, 800D, 850D, 200D II, R50, R, R5, R6, RP, R7, R8, R10, M50, M6 MII
Panasonic	G9, GH5, GH5s, GH6, S5, S1, S1H
OLYMPUS	BMPCC 4K, BMPCC 6K
FUJIFILM	X-T3, X-T4, X-T5, X-H2s
ZCAM	E2
SIGMA	FP