


Suggested Uses:

➤ Tether a camera to your computer.

Optimal Tethering Distance Chart



Compatibility:

TetherPro USB 3.0 to Micro-B cable is compatible with the following digital cameras:

Canon

[CANON 5DS](#) ➤ [CANON 5DS R](#) ➤ [CANON EOS 1D X MARK II](#) ➤ [CANON EOS 5D MARK IV](#) ➤
[CANON EOS 7D MARK II](#) ➤

Fuji

[FUJI X-H1](#) ➤ [FUJI X-T2](#) ➤ [FUJIFILM GFX 50S](#) ➤

Leica

[LEICA SL](#) ➤

Mamiya Leaf

[MAMIYA LEAF CREDO WS 50](#) ➤ [MAMIYA LEAF CREDO WS 60](#) ➤ [MAMIYA LEAF CREDO WS 80](#) ➤

Nikon

[NIKON D5](#) ➤ [NIKON D500](#) ➤ [NIKON D800](#) ➤ [NIKON D800E](#) ➤ [NIKON D810](#) ➤
[NIKON D810A](#) ➤ [NIKON D850](#) ➤

Panasonic Lumix

[PANASONIC LUMIX G9](#) ➤

Pentax

[PENTAX 645Z](#) ➤ [PENTAX K-3](#) ➤ [PENTAX K-3 II](#) ➤

Samsung

[SAMSUNG NX1](#) ➤