

In the Box



Osmo Action 5 Pro
× 1



Osmo Action Extreme
Battery Plus (1950 mAh)
× 3



Osmo Action
Horizontal-Vertical
Protective Frame
× 1



Osmo Action Quick-
Release Adapter Mount
× 1



Osmo Action Quick-
Release Adapter Mount
(Mini)
× 1



Osmo Action Curved
Adhesive Base
× 1



Osmo Locking Screw
× 2



Type-C to Type-C PD
Cable
× 1



Osmo Action
Multifunctional Battery
Case 2
× 1




Osmo 1.5m Extension
Rod
× 1



Osmo Action 5 Pro
Rubber Lens Protector
× 1



Osmo Action 5 Pro
Glass Lens Cover
× 1



Osmo Action Anti-Slip
Pad
× 1



DJI Logo Sticker
× 1