# INSTRUCTIONS

# XC Series Tripod Instructions

#### Contents

Tripod with Quick Release Shoe Short Column Hand Strap Allen Wrenches

# **Extending Legs**

- 1) Press Leg Lock and extend tripod Leg to one of 3 positions
- 2) Loosen Leg Locks and extend legs to desired length and retighten locks

# Removing Center Column & Installing Hand Strap

- 1) Unscrew Weight Hook and the base of the Center Column
- 2) Loosen Both Locking Nut and the Upper Center Column Lock
- 3) Lift Center out from tripod
- 4) Slip strap through the center column and slide it to the top
- 5) Replace Center Colum back into tripod and replace Weight Hook

#### Setting up Monopod

- 1) Look for leg the is marked "Monopod"
- 2) Unscrew leg from tripod
- 3) Remove Center Column from tripod (review instructions above)
- 4) Screw both pieces together and adjust to desired height

#### **Ball Head Instructions**

# Remove Quick Release Shoe

- 1) Loosen Thumb Screw on the side of the Quick Release Platform
- 2) Press Quick Release button on the side of the Platform and slide the Shoe off Platform
- 3) Screw shoe unto the camera base and reverse removal process

#### Vertical/Horizontal position

- 1) Loosen Large Thumb Screw on the base of the tripod head
- 2) Set Camera to desired position and tighten Thumb Screw

### **Folding Tripod**

- 1) Loosen Center Column and lift to its highest position and retighten both locking nut and Upper Center Column Lock
- 2) Loosen Leg Locks and bring legs to their lowest height
- 3) Press Leg Locks and lift legs till they meet with the center column







Monopod

Leg Lock

Bubble Leve

